



This document accompanies the pre-configured EnGenius Link package sold by Broadcast Warehouse.

EnGenius EOC-8610+ Quick Start Guide

Congratulations on buying an EnGenius EOC-8610+ package that has been pre-configured for ease of deployment. The units do not require any additional set-up for use as a point-to-point link. The diagram below demonstrates how they should be connected using the included inline power injector.

Also shown is the use of an optional network switch to allow access to the EOC-8610+ devices from a PC. This allows configuration of the units should it be necessary to change settings such as the wireless network's SSID and transmission frequency.

When logging in to the EOC-8610+ devices over Ethernet, the default access details are:

Username: (blank)

Password: broadcast

IP Address: 192.168.1.1 and 192.168.1.2

For further information please consult the appropriate product user manuals. These can be found by clicking on the 'Downloads' tab of the product's page on www.broadcastwarehouse.com.

